



Smartphone
SGH-i600
User's Guide



Contents

Features	02
precautions	02
Phone Layout	03
Get started	04
Step outside the phone	04
Unpack	05
Solving Problem	06

Features

Games

- Your device includes fun games, such as Bubble Breaker and Solitaire, in Games.

Calculator

- The calculator allows you to perform general mathematical functions, such as addition, subtraction, multiplication, and division.

Smart Converter

- In Smart Converter, you can perform unit conversions.

Voice Assist

- Voice Assist is a speech recognition program that enables you to launch programs or dial contacts by speaking an associated command into the microphone.

Picxel Viewer

- Picxel Viewer allows you to view documents on your device without any file-conversion or loss of content.

File Explorer

- The File Explorer program allows you to open an explorer window similar to a desktop Windows based system.

Task Manager

- Your device is a multi-tasking device. It can run more than one program at the same time. However, multi-tasking may cause hang-ups, freezing, memory problems, and additional power consumption. To avoid these problems, end unnecessary programs using Task Manager.

Beaming with Bluetooth

- Bluetooth is a short-range wireless communications technology.

Precautions

Read these guidelines before using your wireless device. Failure to comply with them may be dangerous or illegal.

Drive safely at all times

- Do not use a hand-held phone while driving. Park your vehicle first.

Switch off the device when refuelling

- Do not use the device at a refuelling point (service station) or near fuels or chemicals.

Switch off in an aircraft

- Wireless devices can cause interference. Using them in an aircraft is both illegal and dangerous.

Switch off the phone near all medical equipment

- Hospitals or health care facilities may be using equipment that could be sensitive to external radio frequency energy. Follow any regulations or rules in force.

Interference

- All wireless phones may be subject to interference, which could affect their performance.

Precautions

Be aware of special regulations

- Meet any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger.


Water resistance

- Your device is not water-resistant. Keep it dry.

Sensible use

- Use only in the normal position (held to your ear). Avoid unnecessary contact with the antenna when the phone is switched on.

Emergency calls

- Key in the emergency number for your present location, then press .

Keep your phone away from small children

- Keep the device and all its parts, including accessories, out of the reach of small children.


Accessories and batteries

- Use only Samsung-approved batteries and accessories, such as headsets and PC data cables. Use of any unauthorised accessories could damage you or your phone and may be dangerous.

Qualified service


- Only qualified service personnel may install or repair your device. Failure to do so may invalidate the warranty.

Phone Layout




Get started


Insert the SIM card.



Remove the battery cover.



Insert the battery.



Plug the travel adapter into the phone.



Step outside the phone

Make or answer calls

Making a call

You can make a phone call using the number keypad. As well as normal voice calls, you can make video conference calls in a 3G (UMTS) network.

To make a voice call:

1. On the Home screen, enter a number including an area code.

2. Press to make a call.

When a call is connected, the call duration displays. During a call, you can use several call options. For details, see page 58.

To adjust the audio volume during a call, press / to increase or decrease the volume level.

3. Press to end the call.

To make a video call:

1. From the Home screen, enter a number including an area code.

2. Press the Menu soft key and select Video call.

Answering a Call

When a call comes in and the device rings or vibrates, depending on the ringer setting:

1. Press the Answer soft key or to answer the call.

2. Press the Ignore soft key or press to reject the call.

You can also press and hold / to reject the call.

3. Press / to mute the ringer.

Unpack

Make sure you have each item

- Phone
- Travel adapter
- Battery
- User's Guide

You can obtain various accessories from your local Samsung dealer.

Note: • The items supplied with your phone and the accessories available at your Samsung dealer may vary, depending on your country or service provider.

Solving Problem

When you switch your phone on, the following messages may appear

“Insert SIM”

- Make sure that the SIM card is correctly installed

“Phone Lock”

- The automatic locking function has been enabled.
You must enter the phone's password before you can use the phone.

Enter PUK

- The PIN code was entered incorrectly three times in succession and the phone is now blocked.
Enter the PUK supplied by your service provider.

Enter PIN

- You are using your phone for the first time.
You must enter the Personal Identification Number (PIN) supplied with the SIM card.
- The PIN Check feature is enabled. Every time the phone is switched on, the PIN has to be entered. To disable this feature, use the PIN check menu.

“No Service,” “Network Failure,” or “Not Done” displays

- The network connection has been lost. You may be in a weak signal area. Move and try again.
- You are trying to access an option for which you have not taken out a subscription with your service provider. Contact the service provider for further details.

You have entered a number but it was not dialled

- Make sure that you have pressed SEND
- Make sure that you have accessed the right cellular network.
- Make sure that you have not set an outgoing call barring option.

A caller cannot reach you

- Make sure that your phone is switched on. (Press END for more than one second.)
- Make sure that you are accessing the correct cellular network.
- Make sure that you have not set an incoming call barring option.

Your voice is not heard at the other end

- Make sure that you have switched on the microphone.
- Make sure that you are holding the phone close enough to your mouth.
The microphone is located at the bottom of the phone.

The phone starts beeping and “Battery Low” flashes on the display

- Your battery is insufficiently charged. Recharge the battery.

The audio quality of the call is poor”

- Check the signal strength indicator on the display (📶).
The number of bars indicates the signal strength from strong (📶) to weak (📶).
- Try moving the phone slightly or moving closer to a window if you are in a building.

No number is dialled when you re-call a Address entry

- Use the Phonebook feature to ensure the number has been stored correctly.
- Store the number again, if necessary.

The battery doesn’t charge properly or the phone sometimes turns itself off

- Wipe the charging contacts both on the phone and on the battery with a clean soft cloth.

If the above guidelines do not help you to solve the problem, take note of

- The model and serial numbers of your phone
- Your warranty details
- A clear description of the problem